BRIGHTEX FL-11

www.Brightexlabs.com
For questions or support please contact:
support@brightexlabs.com

INSTRUCTIONS FOR USE:
BRIGHTEX FL-11:

5 MODES
600 LUMENS LED FLASHLIGHT

BATTERIES

- Unscrew the end cap then place the batteries correctly oriented inside:
  - Place the AAA batteries inside the AAA adaptor and then place the adaptor inside with the arrow pointing inwards.
  - Place inside the plastic tube, then insert the 18650 Lithium battery (not provided)
  - Use 26650 Lithium battery (not provided), for maximum operation time. Unscrew the inner aluminum adaptor from the top part of the battery compartment, using round nose pliers (not provided), then place the battery inside.
- Close the end cap tightly after batteries have been inserted.
- Use either 3 x AAA Alkaline batteries (do not mix old with new) or One 18650/26650 rechargeable High Quality Lithium battery and battery charger (not provided).
- To benefit from the 600 Lumens, use a Fully Charged Lithium battery.
- Remove batteries during storage and transport, to extend the battery life and to prevent leakage of batteries into the battery compartment.
- Dispose of the used batteries properly.

1. End Cap

2. AAA Adaptor

3. AAA Adaptor Inside Flashlight

4. 18650 battery inside Plastic Tube

5. 18650 battery inside flashlight

6. Aluminum Adaptor

7. Taking Out the Aluminum Adaptor

8. Flashlight without Aluminum Adaptor

MODES

Use the uniquely designed 5-mode switch for, switching between different modes.

- **Power off:** Fully press the switch, to turn off the flashlight.
- **High light:** Once the flashlight is switched off for over 10 seconds, when you next switch it on, it will a**lways switch on to High Light** mode
- **Operating the different modes:**
  - To switch between the 5 modes **High, Mid, Low, Strobe, SOS.** Simply press the switch half way and the flashlight will switch to the next mode.
  - Switching **On** the flashlight, shortly after it has been switched off (less then 3sec), will switch to the next mode.

MODE	LUMENS*	OPERATION TIME **	DISTANCE*
High	600	2.5 hours	200
Mid	330	5 hours	100
Low	95	15 hours	40
Strobe	600	5 hours	
SOS	600	5 hours	

*Tested values when using Quality Lithium batteries 18650/26650
** When using Quality Lithium battery 26650

LENGTH	WEIGHT
4.5" (115 mm) SMALL & COMPACT	4.1oz (115g)

ZOOM

Utilizing the x2000 incredible powerful zoom.

- **Zoom In:** Push the lens outwards as shown on the flashlight to Zoom In. Due to the powerful zoom, when you fully zoom in you will even see the actual lines of the LED.
- **Zoom Out:** Push the lens inwards as shown on the flashlight to Zoom Out.

POWERFUL ZOOM	
	PUSH LENS OUTWARDS TO ZOOM IN (NARROW BEAM)
	PULL LENS INWARDS TO ZOOM OUT (WIDE BEAM)

CONDITIONS OF USE

The flashlight is waterproof rated IPX5, enabling you to use it in any weather condition.

- Do not subject the flashlight to salt spray or high-alkalinity fluids or placed it inside water.
- Do not use the flashlight at, or expose it to, temperatures above 140 F (60 C).
- At very cold temperatures, battery power and life will be diminished.
- To avoid scratching the lens, do not place the flashlight lens down on a surface.
- Do not meddle with the lens of the torch.

CARE AND CLEANING

Ensure that your flashlight is clean and dry before and after each use and before storage. **DO NOT STORE A WET FLAHSLIGHT.**

- If the flashlight fell into the water, switch it off, take out the batteries and if needed air dry it thoroughly. If water penetrated the lens, carefully unscrew it and air dry it.
- Wipe flashlight with soft fabric after using.
- In case of erosion causing roughness of the flashlight's zoom movement, try to clear and air it. A small amount of silicon grease can be applied, to smoothen the operation of the Zoom.
- Do not artificially heat your headlamp to dry it.
  If your flashlight has been exposed to salt water, the salt has to be cleaned off the flashlight to prevent corrosion.
- Use freshwater to carefully clean the flashlight.
- Do not clean the flashlight in a washing machine, dishwasher or with a high-pressure hose.
- Do not scrub with abrasive substances or surfaces.
- If the battery contacts are corroded, remove the corrosion by sanding lightly with a fine-grain emery cloth.

TROUBLESHOOTING

After pressing the multifunction switch, the flashlight does not work:

- Check that the batteries are oriented correctly inside the flashlight or the AAA adaptor. Make sure the AAA adaptor if used has been placed with the arrow facing inwards.
- Make sure the Lithium 18650 battery, has been placed inside the plastic adaptor.
- When using AAA batteries replace the batteries with new ones.
- When using a 18650/26650 Lithium battery, charge it. Should this not be sufficient, replace the battery with a new one and follow the guide lines of the manufacturer.
- Check the contacts and connections for corrosion and clean if necessary.
- Make sure the battery compartment cap is firmly closed.
- Work the switch several times.

SPARE PARTS

There are no user replaceable parts for this flashlight other than the batteries.

WARNINGS

- A responsible adult must supervise use by children under the age of 12.
- Do not stare directly into the beam or shine it directly into others' eyes. Intense light can damage your eyes or the eyes of those around you.
- Always inspect your flashlight for proper operation prior to using and, for critical situations, carry a second light and sufficient spare batteries.

WARRANTY INFORMATION

This product comes with a 1 year warranty. This is a limited warranty that the product is free from defects in materials and manufacturing. Please visit www.Brightexlabs.com for instruction on how to return the product in the event there is a product defect. The warranty excludes normal wear and tear. The warranty is voided in the event of unauthorized alterations, improper use or care, or from accidents (eg., dropping on a hard surface causing breakage).

The warranty is limited to replacement of the product and/or a refund equal to the purchase price. Drupoint LTD. is not liable for direct, indirect, incidental, or other types of damages arising out of, or resulting from the use of this product. This warranty is in lieu of all other warranties, express or implied, including, but not limited to, implied warranties of merchantability or fitness for a particular purpose.

To view the manual online please go to www.brightexlabs.com/support